

Shannon Telescopes

Don't Get Wedged Out!

Tray Installation Instructions

Standard Wedge Eyepiece Tray

Equatorial



- 1) Attach Altazimuth control to tripod head. Place eyepiece tray on tripod head. Azimuth controls must be aligned with tray opening as shown with three holes aligned around the central hole.



- 2) Place wedge on top of eyepiece tray. Align all holes and snug socket screws, but do not tighten!



- 3) Attach telescope drive base to wedge tilt plate.



- 4) Altazimuth. Place drive base on eyepiece tray and rotate until the 4" x 6" opening is covered. Secure drive base to tripod by tightening the threaded rod from underneath.

Superwedge/UltraWedge Eyepiece Tray

Equatorial



- 1) Attach tangent arm to tripod head. Place eyepiece tray on tripod head. Tangent arm must be aligned with tray opening as shown with three holes aligned around the central hole.



- 2) Place wedge on top of eyepiece tray. Align all holes and snug socket screws, but do not tighten.



- 3) Attach telescope drive base to wedge tilt plate.
- 4) Altazimuth. Place drive base on eyepiece tray. Secure drive base to tripod by tightening threaded rod from underneath.

For a video of installation of ST Eyepiece Accessory Tray go to: [youtube.com/watch?v=bN7DYBF4obg](https://www.youtube.com/watch?v=bN7DYBF4obg)